



INSTALLATION INSTRUCTIONS FOR

MacWireless Power Over Ethernet

For 11n AirPort Extreme Base Station, Short Range (60 m, 200 ft)

Table of Contents

Introduction	1
Installation	1




Introduction

The Power over Ethernet (PoE) kit contains two parts, an injector and a splitter. The two devices look very similar, but examining them closely will reveal the difference. The injector unit has an ethernet connector and a female power jack. The splitter has an ethernet connector and a male power plug. There is a diagram on the back of this sheet showing a correctly assembled system.

Installation

1. Connect the splitter to the WAN ethernet port and power jack on the base station.
2. Connect the injector to the power supply included with the base station and plug it into the wall.
3. Connect the ethernet part of the injector to your network device, such as a router or switch.
4. Connect the injector to the splitter using an ethernet cable (not included). Maximum length is 200 feet.
5. Installation is complete. You can verify you installation by comparing it to the diagram on the right.



Disclaimer: Although this product has been tested and verified, MacWireless does not accept responsibility for loss or damage to any equipment or device. Use at your own risk.