



INSTALLATION INSTRUCTIONS FOR

MacWireless Power Over Ethernet Splitter Kit for 11n AirPort Extreme Base Station





Table of Contents	
Introduction	1
Installation	1

Introduction

Thank you for purchasing a MacWireless Power Over Ethernet (PoE) Splitter kit. Follow the instructions below to set up your PoE kit. There is also a diagram below showing a correctly assembled system.

Installation

1. Find the short DC cable attached to the splitter. Plug it into the power port on your base station.
2. Find the short Ethernet cable attached to the splitter. Plug it into the WAN port on your base station. The WAN port is designated by the following symbol: .
3. Plug an Ethernet cable (not provided) into an available Ethernet port on your PoE switch. Plug the other end of the cable into the PoE splitter. Maximum length for this Ethernet cable is 328 feet.
4. Installation is complete. The green LED on the splitter should be lit, and your base station should now be receiving both power and data.



Disclaimer: Although this product has been tested and verified, MacWireless does not accept responsibility for loss or damage to any equipment or device. Use at your own risk.