



INSTALLATION INSTRUCTIONS FOR

# MacWireless Decoy Dome Camera

## Table of Contents

Introduction	1
Installation	1



## Introduction

Thank you for purchasing a MacWireless Decoy Dome Camera. Please see below for instructions on how to set up your camera.

## Installation

1. Place two AA batteries (not included) in the battery compartment in the back of the unit. The LED will begin flashing at intervals of a few seconds.
2. Screw the two included mounting screws into the wall or ceiling where you would like to mount the decoy camera. The screws should be spaced to match the mounting holes on the back of the decoy.
3. Line up the decoy camera with the screws, push the camera against the wall or ceiling, and turn the unit clockwise, securing the camera.
4. Installation is complete.

*Disclaimer: Although this product has been tested and verified, MacWireless does not accept responsibility for loss or damage to any equipment or device. Use at your own risk.*