



MACINTOSH INSTALLATION INSTRUCTIONS FOR

## MacWireless Antenna For MacWireless AirPort Booster

### Table of Contents

Introduction	1
Installation	1
Troubleshooting	1



### Introduction

Thank you for purchasing a MacWireless antenna. Before installing your antenna, we recommend that you test your current signal level using iStumbler. Compare this result to the signal level after installation to see how much your connection has improved. iStumbler is included on the MacWireless CD in the "Extra Software" directory, and is also available for download at: <http://www.istumbler.net/>

### Installation

1. Power off your booster and the wireless device connected to it.
2. Remove the antenna from your booster if there is one currently installed.
3. Connect your new MacWireless antenna to the booster's antenna jack. The jacks are labeled on the bottom of the booster.
4. Power on your booster and wireless device.

### Troubleshooting

#### I'm not seeing a significant increase in range. What can I do?

1. Verify the physical connections, and make sure that you power-cycle your wireless device after connecting or disconnecting range extending hardware.
2. Aim your antenna appropriately. For more information on how your antenna radiates energy, see the antenna help section of our website: <http://www.macwireless.com/html/help/antenna.html> If you have an antenna from a manufacturer other than MacWireless, consult your product documentation for more information.
3. If you are connecting your booster to an AirPort base station, use the AirPort Admin Utility to verify that your external connection is recognized. Inside the base station configuration area, go to the View menu and choose "Summary" or "Show Summary". You should see "Antenna: External". If you do not, double check the physical connections and power-cycle the base station. If you still do not see the external connection in your Admin Utility, check the hardware on a different base station, if you have one available.

#### Factors Affecting Range and Performance of All Wireless LAN Systems

Range estimates are typical and require line of sight. Basically that means you will need a clear unobstructed view of the antenna from the remote point in the link. Keep in mind that walls and obstacles will limit your operating range and could even prevent you from establishing a link. Signals generally will not penetrate metal or concrete walls. Trees and leaves are obstructions to 802.11 frequencies so they will partially or entirely block the signal. Other factors that will reduce range and affect coverage area include metal studs in walls, concrete fiberboard walls, aluminum siding, foil-backed insulation in the walls or under the siding, pipes and electrical wiring, furniture, and sources of interference. The primary source of interference in the home will be the microwave oven. Other sources include other wireless equipment, cordless phones, radio transmitters, and other electrical equipment. Due to the increased gain, installing range extender antennas in the presence of interference could actually yield equal or worse range. These solutions work for the vast majority of our customers. However, due to the numerous factors affecting range and performance, we do not guarantee that you will achieve any specific improvement in range for your specific application.

*Disclaimer: Although this product has been tested and verified, MacWireless does not accept responsibility for loss or damage to any equipment or device. Use at your own risk.*